

Parts & Accessories Bulletin

P & A #312



September 12, 1986

CHROME ACORN NUT AND STUD KIT PART NUMBER 91734-85

This bulletin refers to Harley-Davidson kit part number 91734-85. The attached Instruction Sheet has been revised to ensure a tight fit of the studs in wheels of 1987 and later models.

The changes made on the Instruction Sheet begin at the end of step 4 and are as follows;

4. Threads...Loctite Primer. Start coarse threaded end of stud into holes in hub. If stud is a loose fit use Loctite from kit on these threads. If stud is a tight fit go to step 5.

NOTE

The tight fitting studs will usually be found on 1986 and earlier models. The loose fit will usually be found on 1987 and later models.

5. Apply...wheel.

Be sure parts counter staff and service department are aware of this revision. Post a copy nearby and alert customers purchasing this kit of the changes.



FILE IN ACCESSORY GUIDE FOR FUTURE REFERENCE