



NOTE: THE FOLLOWING PARTS ARE UNIQUE TO THE 1984 FXR-POLICE VEHICLES. FOR ALL OTHER PARTS PLEASE REFER TO THE 1984 FXR MODEL PARTS CATALOG, PART NUMBER 99439-84.

FXR — POLICE PARTS**RP1**

RETAIL PRICE	INDEX NO.	PART NO.	N A M E	USED ON
ENGINE				
		16116—84	ENGINE, complete	84 to * — FXRP
		32419—84	IGNITION MODULE	84 to * — FXRP
AIR CLEANER				
		29170—83	COVER, air cleaner	84 to * — FXRP
FRONT BRAKE CALIPER & CONTROLS				
		856	SCREW, front brake line	84 to * — FXRP
		63368	WASHER, front brake line	84 to * — FXRP
		7740	NUT, front caliper (2)	84 to * — FXRP
		44025—80	CALIPER ASSEMBLY, left (black)	84 to * — FXRP
		44026—80	CALIPER ASSEMBLY, right (black)	84 to * — FXRP
		44121—80	CALIPER ASSEMBLY, outer — left (black)	84 to * — FXRP
		44146—77	BLEEDER FITTING, front caliper	84 to * — FXRP
		44151—77	SEAL, piston — front caliper	84 to * — FXRP
		44153—77	BOOT, front caliper	84 to * — FXRP
		44157—77	PISTON, front brake caliper	84 to * — FXRP
		44158—77	PLATE, outer — front brake caliper	84 to * — FXRP
		44161—77	PLATE, inner — front brake caliper	84 to * — FXRP
		44162—77	PIN, front brake caliper (2)	84 to * — FXRP
		44163—80	CALIPER, inner — left (black)	84 to * — FXRP
		44164—80	CALIPER, inner — right (black)	84 to * — FXRP
		44165—77	WASHER, front brake caliper	84 to * — FXRP
		44172—77	BOLT, front brake caliper	84 to * — FXRP
		44173—77	SCREW, caliper mounting (long)	84 to * — FXRP
		44174—77	SCREW, caliper mounting (short)	84 to * — FXRP
		44195—80	CALIPER ASSEMBLY, outer — right (black)	84 to * — FXRP
		44312—84	BRAKE LINE, front control to calipers	84 to * — FXRP
		45013—82	MASTER CYLINDER ASSEMBLY, with hand lever	84 to * — FXRP
		45063—82A	MASTER CYLINDER PISTON KIT	84 to * — FXRP

FRONT WHEEL

	3795	SCREW, brake disc (10)	84 to * — FXRP
	43263—83	LABEL, rim	84 to * — FXRP
	43488—77	SPACER, bearing	84 to * — FXRP
	43883—77	AXLE, front	84 to * — FXRP
	44137—77A	DISC, front brake (2)	84 to * — FXRP

RETAIL PRICE	INDEX NO.	PART NO.	N A M E	USED ON
REAR BRAKE CALIPER & CONTROLS				
	3231B		SET SCREW, brake lever bushing	84 to * — FXRP
	42413—83		BUSHING, with 1/2 - 20 tap hole	84 to * — FXRP
	44207—82		MOUNTING BRACKET, caliper body	84 to * — FXRP

REAR WHEEL & CHAIN HOUSING

717	PLUG, with o-ring	84 to * — FXRP
2002	SCREW, hardware on inward side of chain housing	84 to * — FXRP
3825	BOLT, chain cover assembly (rear) (2)	84 to * — FXRP
4702	BOLT, front bracket mounting (4)	84 to * — FXRP
4812	SCREW, boot mounting (7)	84 to * — FXRP
5738	SPACER, rear disc brake	84 to * — FXRP
6703	WASHER, front bracket mounting (4)	84 to * — FXRP
7036	LOCKWASHER, chain cover assembly (rear) (2)	84 to * — FXRP
7069	LOCKWASHER, hardware on inward side of chain housing ..	84 to * — FXRP
7620W	NUT, hardware on inward side of chain housing	84 to * — FXRP
7676	NUT, chain cover assembly (rear) (2)	84 to * — FXRP
7742	LOCKNUT, boot	84 to * — FXRP
9052	ROLLER BEARING, rear wheel (2)	84 to * — FXRP
11115	O-RING, chain cover assembly (rear)	84 to * — FXRP
11428	PLUG, chain housing fill	84 to * — FXRP
11726	STUD, chain boot	84 to * — FXRP
25402—79A	BRACKET, rear	84 to * — FXRP
25403—82A	CHAIN COVER ASSEMBLY	84 to * — FXRP
25404—80	DECAL, "WARNING — TORQUE WHEEL BOLTS", etc. ..	84 to * — FXRP
25410—79A	SPACER PLATE	84 to * — FXRP
25411—79	PLATE, boot mounting (4)	84 to * — FXRP
25412—79	BOOT, chain (2)	84 to * — FXRP
25413—79	BRACKET, front	84 to * — FXRP
25414—82	SEAL, spacer plate to rear chain housing	84 to * — FXRP
40906—82	SPACER, right	84 to * — FXRP
41087—83	SPACER, between bearings, includes 41088—83 SPACER ..	84 to * — FXRP
41123—79	VALVE CAP	84 to * — FXRP
41191—74	SCREW, ctsk. flat socket hd. (2)	84 to * — FXRP
41521—83	SPROCKET, only — 48 tooth	84 to * — FXRP
41791—79	DISC, rear brake	84 to * — FXRP
43157—83A	VALVE STEM ASSEMBLY	84 to * — FXRP
43265—83	LABEL, warning	84 to * — FXRP
43287—83	SLEEVE	84 to * — FXRP
43289—83	SLEEVE	84 to * — FXRP
43290—82	SPACER, .032 thick	84 to * — FXRP
43291—82	SPACER, .016 thick	84 to * — FXRP
43292—82	SPACER, .008 thick	84 to * — FXRP
43293—82	SPACER, .004 thick	84 to * — FXRP
43294—82	SPACER, .002 thick	84 to * — FXRP
43567—79	SCREW (5)	84 to * — FXRP
43650—82	SPACER WASHER	84 to * — FXRP
43667—82	SPACER, left	84 to * — FXRP
95590—77	WHEEL WEIGHT, 0.50 oz. (black)	84 to * — FXRP
95591—77	WHEEL WEIGHT, 1.0 oz. (black)	84 to * — FXRP

RETAIL PRICE	INDEX NO.	PART NO.	N A M E	USED ON
FRONT FORK				
	6716		WASHER, brake line clamp	84 to * — FXRP
	10031		CLAMP, brake line routing	84 to * — FXRP
	45398—80		FORK SLIDER & TUBE, right	84 to * — FXRP
	45399—80		FORK SLIDER & TUBE, left	84 to * — FXRP
	45400—75		OIL SEAL, sliders (2)	84 to * — FXRP
	45410—75		AXLE HOLDER, left	84 to * — FXRP
	45644—77		SLIDER TUBE, complete — front fork (2)	84 to * — FXRP
	45906—80		SLIDER, right	84 to * — FXRP
	45910—80		DAMPER TUBE, front fork	84 to * — FXRP
	45912—80		SLIDER, left	84 to * — FXRP
	45994—77		AXLE HOLDER, right	84 to * — FXRP
	46018—77		BUSHING, brake caliper — upper (2)	84 to * — FXRP
	46019—77		BUSHING, brake caliper — lower (2)	84 to * — FXRP
	46052—80		SPRING, fork slider (2)	84 to * — FXRP

SEAT

	7686		LOCKNUT (4)	84 to * — FXRP
	11741		U-BOLT, 1/4-20 both ends, seat bracket (2)	84 to * — FXRP
	52018—84		SOLO SEAT ASSEMBLY	84 to * — FXRP
			Consists of besides hardware:	
		2551W	SCREW, frame to seat bracket (4)	
		6703	WASHER, frame to seat bracket (2)	
		52242—83A	SOLO SEAT	
		52255—84	SEAT SUSPENSION KIT	
		52258—84	SEAT BRACKET ASSEMBLY	
		52261—84	SEAT HARDWARE KIT, includes 2667 BOLT, 7041 LOCKWASHER, 7739 LOCKNUT (2)	
	52575—65		AUXILIARY SPRING (2)	84 to * — FXRP

FRAME COVERS & REAR FORK

	7825		LOCKNUT, shaft swing arm (2)	84 to * — FXRP
	47829—83		REAR FORK (without chain guard bracket)	84 to * — FXRP
	66349—81		SIDE COVER, right	84 to * — FXRP
	66350—81		SIDE COVER, left	84 to * — FXRP

FRONT & REAR HIGHWAY BARS

	861		SCREW	84 to * — FXRP
	2851		BOLT (4)	84 to * — FXRP
	2879W		BOLT	84 to * — FXRP
	4726		BOLT (2)	84 to * — FXRP
	6701		WASHER (5)	84 to * — FXRP
	7038		LOCKWASHER (5)	84 to * — FXRP
	49017—82A		HIGHWAY BAR KIT, includes hardware	84 to * — FXRP
	49021—83		HIGHWAY BAR (rear)	84 to * — FXRP
	49120—82		SPACER	84 to * — FXRP

RETAIL PRICE	INDEX NO.	PART NO.	N A M E	USED ON
FOOTBOARDS				
	4816		SCREW, footboard bracket, mounting (8)	84 to * — FXRP
	34610—83		SHIFTER PEDAL (heel & toe)	84 to * — FXRP
	34611—65		COVER, shift lever (rubber) (2)	84 to * — FXRP
	50602—83		FOOTBOARD BRACKET	84 to * — FXRP
	50603—74A		FOOTBOARD ASSEMBLY (2)	84 to * — FXRP
			Consists of:	
		50614—66	PAD, footboard	
		50619—74A	UPPER PLATE, only	
		50620—74	RUBBER MOUNT (4)	
	50627—84		FOOTBOARD BRACKET (2)	84 to * — FXRP
	50628—84		MOUNTING BLOCK, footboard	84 to * — FXRP
	50635—82		BOLT, footboard hinge (4)	84 to * — FXRP

SHOCK ABSORBERS

54468—79A	SPRING, shock absorber	84 to * — FXRP
54501—82	SHOCK ABSORBER ASSEMBLY (2)	84 to * — FXRP
54522—82	DAMPER ASSEMBLY, shock absorber	84 to * — FXRP

HANDLEBAR

853	SCREW, handlebar clamp (3)	84 to * — FXRP
2661W	SCREW, siren switches bracket (3)	84 to * — FXRP
2889	BOLT, speaker brace (2)	84 to * — FXRP
5978W	SPACER, handlebar clamp (2)	84 to * — FXRP
7748W	NUT, handlebar clamp (2)	84 to * — FXRP
55916—82	HANDLEBAR	84 to * — FXRP

WINDSHIELD

2430	SCREW, adjustment bracket (2)	84 to * — FXRP
2725	SCREW, windshield braces (7)	84 to * — FXRP
4391	BOLT, windshield (2)	84 to * — FXRP
6333	WASHER, windshield bracket (4)	84 to * — FXRP
6702	WASHER, windshield bracket (4)	84 to * — FXRP
7030W	LOCKWASHER, windshield braces & adjustment bracket (9)	84 to * — FXRP
7651	ACORN NUT, windshield braces & adjustment bracket (5)	84 to * — FXRP
7654W	NUT, outer bracket & tape bracket (4)	84 to * — FXRP
58002—84	WINDSHIELD ASSEMBLY	84 to * — FXRP
58026—77	WIND DEFLECTOR	84 to * — FXRP
58050—78	WINDSHIELD BRACE, inner	84 to * — FXRP
58051—78	WINDSHIELD BRACE, outer	84 to * — FXRP
58052—78	WINDSHIELD BRACE, tape (2)	84 to * — FXRP
58078—49	BRACKET, adjustable — right	84 to * — FXRP
58079—49	BRACKET, adjustable — left	84 to * — FXRP
58406—75	BRACKET, outer — right	84 to * — FXRP
58408—75	BRACKET, outer — left	84 to * — FXRP
58417—77	BRACKET, outer — tape (2)	84 to * — FXRP
68629—84	FORK BRACKET, right	84 to * — FXRP
68632—84	FORK BRACKET, left	84 to * — FXRP

RETAIL PRICE	INDEX NO.	PART NO.	N A M E	USED ON
HEADLAMP				
	7068		LOCKWASHER, headlamp mounting	84 to * — FXRP
	7614		SPEED NUT, headlamp trim bracket to headlamp bracket (2) .	84 to * — FXRP
	7880		NUT, headlamp mounting	84 to * — FXRP
	8519		RIVET, directional flasher to headlamp	84 to * — FXRP
	9952		FLASHER CLIP, directional flasher to headlamp	84 to * — FXRP
	67815—59A		WASHER, headlamp mounting	84 to * — FXRP
	67833—75		BRACKET, headlamp trim	84 to * — FXRP

FENDERS

2824W	SCREW, rear fender hole (2)	84 to * — FXRP
2882W	BOLT, front fender brace to slider (4)	84 to * — FXRP
9965W	CLAMP, electronic ignition wire	84 to * — FXRP
11430	GROMMET, rear fender	84 to * — FXRP
11431	GROMMET, speedometer cable guide	84 to * — FXRP
38622—78	GUIDE, speedometer cable	84 to * — FXRP
59573—83	REAR FENDER, includes 59569—83 STRAP	84 to * — FXRP

FUEL TANK

3651	SCREW, console to fuel tank	84 to * — FXRP
7743	SPEED NUT, console (2)	84 to * — FXRP
61147—84	CONSOLE, fuel tank assembly	84 to * — FXRP
	Consists of besides console:	
2072W	SCREW, lower console (2)	
8519	RIVET, console clip (2)	
9952	CLIP, console (2)	
53413—69	PLUG, console — left	
67843—70	TOGGLE SWITCH, 4-way flasher	
67846—70	NUT, toggle switch	
76193—80	PLUG, console — right	
61168—81A	DECAL, fuel tank (white on black) (2)	84 to * — FXRP
68541—81A	FLASHER ASSEMBLY	84 to * — FXRP
69618—82	CABLE ASSEMBLY, fuel gauge ground	84 to * — FXRP
	Consists of:	
9856	WIRE TERMINAL, ring type	
9859	WIRE TERMINAL, ring type	
70329—84	CABLE FLASHER, includes 9900 WIRE TERMINAL (2) ...	84 to * — FXRP
70901—77	SCREW, console (2)	84 to * — FXRP

EXHAUST SYSTEM

65656—82A	MUFFLER, front (chrome)	84 to * — FXRP
65657—82A	MUFFLER, rear (chrome)	84 to * — FXRP

RETAIL PRICE	INDEX NO.	PART NO.	N A M E	USED ON
-----------------	--------------	-------------	---------	---------

SPEEDOMETER & TACHOMETER

67043—75C	SPEEDOMETER, kilo / mph (185 kph)	84 to * — FXRP
	Consists of besides speedometer:	
67310—74	ACORN NUT, lower cover to speedometer head (2)	
67311—74	WASHER, lower cover to speedometer head (2)	
67312—74	LOCKWASHER, lower cover to speedometer head (2)	
67313—74	LOWER COVER	
67314—74	GROMMET, speedometer head mounting (4)	
67317—74	GASKET, foam rubber	
67318—74	SOCKET, with wire — speedometer light	
67325—76	KNOB, reset (with shaft)	
71090—64	BULB, speedometer	
72038—71	TERMINAL, socket	
67059—84	SPEEDOMETER, police (120 mph)	84 to * — FXRP
	Consists of besides speedometer:	
67310—74	ACORN NUT, lower cover to speedometer head (2)	
67311—74	WASHER, lower cover to speedometer head (2)	
67312—74	LOCKWASHER, lower cover to speedometer head (2)	
67313—74	LOWER COVER	
67314—74	GROMMET, speedometer head mounting (4)	
67317—74	GASKET, foam rubber	
67318—74	SOCKET, with wire — speedometer light	
67325—76	KNOB, reset (with shaft)	
71090—64	BULB, speedometer	
92073—81	PLUG, lower cover	
92075—77	BRACKET, speedometer support	
67060—79A	SPEEDOMETER CABLE, includes 67064—81 CABLE, speedometer	84 to * — FXRP
67127—73	SPEEDOMETER DRIVE (front wheel)	84 to * — FXRP

TAIL LAMP, TURN SIGNALS & INDICATOR LAMPS

3767B	BOLT, directional bracket mounting to fender (2)	84 to * — FXRP
7230	LOCKWASHER, directional bracket mounting to fender (2)	84 to * — FXRP
59980—84	MOUNTING BRACKET ASSEMBLY, license plate light to fender	84 to * — FXRP
	Consists of:	
8211	RIVET, mounting plate to bracket (8)	
59981—84	MOUNTING PLATE, license plate light	
59987—83	BRACKET, license plate light	
59989—84	LICENSE PLATE LIGHT (blue)	84 to * — FXRP

RETAIL PRICE	INDEX NO.	PART NO.	N A M E	USED ON
TAIL LAMP, TURN SIGNALS & INDICATOR LAMPS (CONT'D)				
	59996—84		CABLE, license plate light	84 to * — FXRP
			Consists of besides wiring:	
		9863	WIRE TERMINAL, ring type, plug to license plate mounting screws (2)	
		72038—71	SOCKET, license plate light	
		72039—71	PIN, single socket, wires to plugs (2)	
		72043—71	CONNECTOR, pin to wires	
		72044—71	CONNECTOR, connector to pin	
	67851—75		INDICATOR LIGHT ASSEMBLY (green) includes	
		72038—71	SOCKET (2)	84 to * — FXRP
	68468—84		INDICATOR LIGHT ASSEMBLY	84 to * — FXRP
			Consists of:	
		68608—83	SPEED NUT	
		72038—71	TERMINAL, single pin	
	68520—63		O-RING, lamp mounting (2)	84 to * — FXRP
	68536—75		INDICATOR LIGHT ASSEMBLY (red) includes 72038—71 SOCKET	84 to * — FXRP
	68557—70A		LAMP WITH WIRE, rear turn signal — 12V (amber)	84 to * — FXRP
			Consists of:	
		68521—63A	GASKET, lens (2)	
		68554—82	WIRE, terminals to directional (black) (2)	
		68571—63A	LENS, rear (amber) (2)	
		68586—63A	SCREW, lens mounting (4)	
	68560—84		INDICATOR LIGHT BRACKET	84 to * — FXRP
	68597—83		INDICATOR LIGHT ASSEMBLY, hi-beam (See 68468—84 for components)	84 to * — FXRP
	68643—83		BRACKET, rear turn signal lamps	84 to * — FXRP
	70116—84		CABLE ASSEMBLY, rear directional (right)	84 to * — FXRP
	70134—84		CABLE ASSEMBLY, rear directional (left)	84 to * — FXRP
			Above assemblies consist of besides wiring:	
		9860	WIRE TERMINAL, ring type	
		72039—71	PIN, single socket	
		72052—79	RECEPTACLE, side light wire	
		74536—77A	SOCKET, wiring harness	
		74539—77A	PIN, wiring harness	
	70576—68		WIRE CONNECTOR (2)	84 to * — FXRP

PURSUIT LAMPS

	14021—83		DECAL, pursuit lamp	84 to * — FXRP
	68599—83		SPOTLIGHT SUPPORT ASSEMBLY	84 to * — FXRP
	68646—84		PURSUIT LAMP ASSEMBLY (red) includes 68727—64A PURSUIT LAMP SEALED UNIT (red lens)	84 to * — FXRP
			(See below for components besides lamp)	
	68647—84		PURSUIT LAMP ASSEMBLY (blue) includes 68728—64 PURSUIT LAMP SEALED UNIT (blue lens)	84 to * — FXRP
			(See below for components besides lamp)	
			Above assemblies consist of besides lamp:	
		68627—62A	WIRE ASSEMBLY, pursuit lamp to door	
		68672—38	SCREW, pursuit lamp door	
		68690—69	WIRE CLIP, pursuit lamp	
		68725—62	LAMP MOLDING, pursuit lamp	
		72038—71	SOCKET, single pin	

RETAIL PRICE	INDEX NO.	PART NO.	N A M E	USED ON
PURSUIT LAMPS (CONT'D)				
	68693—38		SWIVEL WASHER (2)	84 to * — FXRP
	68720—62		CLAMP BLOCK (2)	84 to * — FXRP
	69539—84		CABLE ASSEMBLY, handlebar switch to flasher & lights ..	84 to * — FXRP
			Consists of besides wiring:	
		9856	WIRE TERMINAL, ring type, to handlebar switch (2)	
		9938	WIRE TERMINAL (brass), to pursuit flasher	
		10006	PLASTIC STRAP (black) conduit to wires	
		72034—71	HOUSING, 2 terminal (black), to wire harness lights	
		72038—71	SOCKET, single pin, to 2 terminal housing (2)	
	70091—84		CONNECTING WIRE, pursuit lamps to flasher	84 to * — FXRP
			Consists of besides wiring:	
		72035—71	CONNECTOR, double pin	
		72039—71	PIN TERMINAL (2)	
		72275—74	CONNECTOR TAB, 2 terminal	
	71431—83		TOGGLE SWITCH, pursuit lamps	84 to * — FXRP
	91152—83		BRACKET, toggle switch mounting	84 to * — FXRP

SIGNAL LAMP

	384		ROLL PIN, swivel ball	84 to * — FXRP
	990W		SCREW, base plate to lens (3)	84 to * — FXRP
	1040		SCREW, ball socket	84 to * — FXRP
	2587		SCREW, clamp (lamp mast mounting) (2)	84 to * — FXRP
	7112		LOCKWASHER, base plate to lens (3)	84 to * — FXRP
	7609W		LOCKNUT, ball socket	84 to * — FXRP
	7626W		LOCKNUT, clamp (lamp mast mounting) (2)	84 to * — FXRP
	67604—84		MOUNTING KIT, rear signal lamp	84 to * — FXRP
			Consists of:	
		2591	SCREW, mounting bracket, signal lamp mast	
		2623W	SCREW	
		2646	SCREW, clip to wiring bracket	
		4053W	BOLT, fender to top support bracket	
		6182W	WASHER, mounting bracket signal lamp mast (2)	
		6192	WASHER, cable clip screw	
		6702	WASHER, mounting bracket signal lamp (2)	
		7015	LOCKWASHER	
		7315	LOCKWASHER	
		7609W	LOCKNUT, wiring bracket screw	
		7626W	LOCKNUT, mounting bracket signal lamp mast	
		7725	LOCKNUT, signal lamp bracket clamp & fender support (2)	
		10006	CABLE STRAP (8)	
		10007	CABLE STRAP (2)	
		10009	CLIP, cable signal lamp	
		67607—68	MOUNTING BRACKET, signal lamp mast	
		67609—68	WIRING BRACKET	

RETAIL PRICE	INDEX NO.	PART NO.	N A M E	USED ON
SIGNAL LAMP (CONT'D)				
	67604—84		MOUNTING KIT, components — cont'd.	
		67610—78	BRACKET, lamp support — top	
		67844—70	TOGGLE SWITCH, spotlight includes	
			67846—70 NUT, toggle switch	
		68476—73	CLAMP, signal lamp bracket	
		68478—73	SCREW, signal lamp bracket clamp	
		68479—73	SCREW, signal clamp	
		70136—84	CABLE, rear signal lamp includes 9857 TERMINAL & 9900 CONNECTOR	
		70153—84	CABLE, 4-way flasher to signal lamp includes 9900 CONNECTOR, 72034—71 HOUSING & 72038—71 SOCKET	
		70574—68	RETAINER, wiring bracket (2)	
	67627—64C		LAMP AND LENS ASSEMBLY, less mast, with cable, in- candescent — 12V (red) includes 67670—77 LENS (red). (See below for components besides lens)	84 to * — FXRP
	67633—77A		LAMP AND LENS ASSEMBLY, less mast, with cable, in- candescent — 12V (blue) includes 67688—77 LENS (blue) (See below for components besides lens)	84 to * — FXRP
	67650—78		OUTER MAST SECTION	84 to * — FXRP
	67651—59		CENTER MAST SECTION	84 to * — FXRP
	67652—59		INNER MAST SECTION	84 to * — FXRP
	67655—59		BALL SOCKET	84 to * — FXRP
	67656—59		WASHER, ball socket	84 to * — FXRP
	67657—59		SWIVEL BALL	84 to * — FXRP
	67658—59		SPRING, ball washer	84 to * — FXRP
	67659—59		RUBBER TIP, lamp mast	84 to * — FXRP
	67660—59		CLAMP, lamp mast mounting (2)	84 to * — FXRP
	67661—59		BASE PLATE, ball socket	84 to * — FXRP
	67662—59		RETAINING RING, mast section	84 to * — FXRP
	67686—77		CABLE, rotating lamp	84 to * — FXRP
	67627—64C		LAMP AND LENS ASSEMBLY	84 to * — FXRP
	67633—77A		LAMP AND LENS ASSEMBLY	84 to * — FXRP
			Above assemblies consist of besides lens:	
		67661—59	COVER PLATE, ball socket	
		67671—80	BULB, rotating lamp — 12V (incandescent)	
		67672—80	SPRING, bulb contact	
		67674—80	ADAPTER, bulb	
		67675—77	RETAINING RING, bulb	
		67676—77	WASHER, nylon	
		67677—77	WASHER, nylon — drive wheel	
		67678—77	DRIVEN WHEEL AND MIRROR	
		67679—77	RUBBER CUSHION, driven wheel and mirror	
		67680—77	DRIVE MOTOR — 12V	
		67681—77	BOLT, motor (2)	
		67682—77	PLUG, base plate (2)	
		67683—77	RETAINING BAND, base plate	
		67684—77	BUSHING, base plate — signal lamp kit	
		67685—77	BASE PLATE, signal lamp kit	
		67686—77	CABLE, rotating lamp	

RETAIL PRICE	INDEX NO.	PART NO.	N A M E	USED ON
MISCELLANEOUS WIRING & ELECTRICAL				
	8672		RIVET, circuit breaker clip	84 to * — FXRP
	70002—84		WIRING HARNESS, electric siren	84 to * — FXRP
			Consists of besides wiring:	
		9856	WIRE TERMINAL, ring type (4)	
		9858	WIRE TERMINAL, ring type	
		9862	WIRE TERMINAL, ring type	
		9871	WIRE TERMINAL, ring type	
		9885	WIRE TERMINAL	
		9887	CONNECTOR WIRE (female) (5)	
		9896	WIRE TERMINAL, female spade type (4)	
		9938	WIRE TERMINAL (brass)	
		10065	PLASTIC STRAP (black) (5)	
		72034—71	HOUSING, 2 terminal (black)	
		72038—71	SOCKET, single pin (2)	
		74539—83	PIN, single socket (5)	
		74563—65	DIODE	
	70104—84		CIRCUIT BREAKER WIRE, siren includes 9862 TERMINAL	84 to * — FXRP
	70122—84		MAIN WIRING HARNESS	84 to * — FXRP
	70970—82		IGNITION PANEL ASSEMBLY	84 to * — FXRP
	71774—77		INSULATOR, female spade terminal (2)	84 to * — FXRP

SADDLEBAGS

	3960W	BOLT, rear saddlebag guard mounting (4)	84 to * — FXRP
	3991	BOLT, saddlebag to frame mounting (4)	84 to * — FXRP
	4415	BOLT, saddlebag brace to frame (2)	84 to * — FXRP
	4716W	BOLT, braces to saddlebag (12)	84 to * — FXRP
	6733	WASHER, braces to saddlebag (12)	84 to * — FXRP
	7565	WELL NUT, braces to saddlebag (12)	84 to * — FXRP
	7710W	LOCKNUT, saddlebag to frame mounting (4)	84 to * — FXRP
	7725	LOCKNUT, rear saddlebag guard mounting (4)	84 to * — FXRP
	7775	LOCKNUT, saddlebag brace to frame (2)	84 to * — FXRP
	90782—84	MOUNTING BRACKET, frame to saddlebag	84 to * — FXRP
	90783—84	MOUNTING BRACKET, frame to saddlebag	84 to * — FXRP
	90985—84	SADDLEBAG ASSEMBLY (right)	84 to * — FXRP
	90986—84	SADDLEBAG ASSEMBLY (left)	84 to * — FXRP
	90987—84	SADDLEBAG GUARD (rear)	84 to * — FXRP

SIREN

	14021—83	DECAL, siren	84 to * — FXRP
	91193—84	SIREN KIT	84 to * — FXRP
		Consists of:	
		4017 BOLT (3)	
		6035 BOLT (4)	
		6036 WASHER (2)	
		7686 LOCKNUT (2)	
		7739 LOCKNUT, speaker mounting bracket to front highway bar (7)	
		10006 CABLE STRAP	
		10050 CLAMP (3)	
	70002—84	WIRING HARNESS, electric siren (See WIRING & MISC. ELECTRICAL Section for components)	
	71432—83	SWITCH, electronic siren	
	91127—82	MOUNTING BRACKET, speaker	
	91149—83	MOUNTING BRACKET, electronic siren	
	91150—82	AMPLIFIER ASSEMBLY	
	91153—83	SPEAKER ASSEMBLY (See below for components)	
	91159—82	U-BOLT, speaker bracket mounting (2)	

RETAIL PRICE	INDEX NO.	PART NO.	N A M E	USED ON
-----------------	--------------	-------------	---------	---------

SIREN (CONT'D)

91153—83			SPEAKER ASSEMBLY	84 to * — FXRP
			Consists of:	
		3802W	BOLT (2)	
		6035	BOLT (4)	
		6036	WASHER (2)	
		7686	LOCKNUT (4)	
		9886	CONNECTOR WIRE (male) (2)	
		10006	CABLE STRAP	
		91127—82	MOUNTING BRACKET, speaker	
		91159—82	U-BOLT, speaker bracket mounting (2)	

RADIO SECTION

76181—83			BRACKET, radio speaker	84 to * — FXRP
76182—83			BRACE, speaker mounting	84 to * — FXRP
76183—83			MOUNTING BRACKET, radio (rear)	84 to * — FXRP
76229—84			MICROPHONE KIT	84 to * — FXRP
			Consists of:	
		2512	SCREW (2)	
		76230—84	CABLE ASSEMBLY, phone jack includes 9886 WIRE CONNECTOR (3) & 76214—83 RECEPTICAL	